

Addendum

- 581** Tape two straight edges to the bottom and side of the fuselage as shown (you may have to do this step in two parts if your straight edges are not long enough). Start at the tip of the tail and end 15mm away from the corner of the fuselage at the landing gear mount. Cut this bevel with a sharp craft knife. Blend the newly cut bevel into the roundness of the nose with your sanding block. Repeat on the other side.

